

WINDOWSPAN

HOW TO SET UP YOUR WINDOWSPAN

1. Lay the Windowspan on the ground with the 'Ladder Lugs' upright and 'ladder Lock Bar' removed, and the recess lock lugs fully retracted.
2. Place the ladder with top rung directly over the Windowspan 'cross bar' and 90 degrees to it.
3. Slide the 'Ladder Lugs' up to the ladder sides in a snug fit and tighten up the 'Ladder Lugs'.
4. Slide the 'Ladder Lock Bar' through the 'Ladder Lug', ladder top rung and second 'Ladder Lug', ensuring that large Pan Washer is adjacent, to and on the outside of both 'Ladder Lugs', slide on the lock washer and screw on the 8mm nut finger tight ONLY.
5. Grip the ladder rung and the 'Cross Bar' with your left hand and squeeze together to ensure that the 'Cross Bar' and ladder sides are **flat against each other** and tighten up the lock nut. DO NOT OVERTIGHTEN SO AS TO BEND THE 'LADDER LUGS'.